

Read it first, please.

1. Check if there is no damage to cargo/shipment. If there is any damage, contact shipper immediately or do not accept damaged cargo/shipment
2. Before you connect power cables please check if hard drives are settled properly in bays. Sometime they move out a little and disconnect.
3. After mechanical inspection and eventual corrections, connect mouse, keyboard and monitor and you can connect server to power.
4. PHT Media Server should start automatically.
5. Check info on monitor.
6. After system is ON go to step B
7. If you have any doubts or question, contact me immediately.